



3FT CATERER GAS BARBECUE

- 1) Stand the Barbecue upright.
- 2) Connect the regulator to propane gas cylinder tightly.
- 3) Ensure the gas control knob is turned off and that the dial on the regulator is turned to 10 for maximum gas feed.
- 4) Locate the ignition hole underneath the barbecue.
- 5) Turn on the gas at the bottle.
- 6) Hold a lighted match under the ignition hole and turn on the gas control knob.
- 7) This should suck the flame into the ignition hole and ignite the gas, lighting the barbecue.
- 8) Heat level can be adjusted with the dial on the regulator (more accurate) or the gas control knob on the gas control knob and turn off the gas at the bottle the barbecue.
- 8) When finished cooking turn off the gas control knob and turn off the gas at the bottle.

Tel: 01379 652100 **Emergency on call: 07860 466753**

Email: office@cmahire.co.uk www.cmahire.co.uk

Unit 9 –10 Forge Business Centre, Upper Rose Lane, Palgrave, Diss, Norfolk IP22 1AP