



Electric Water Boiler Instructions.

1. Check that the appliance is plugged in to the mains socket and is switched on.
2. Fill the boiler to the fill point and turn the control dial round to 6 (or highest number).
3. The water will be at boiling temperature after around 45 minutes.
4. Once boiling, reduce the heat by turning down the control knob to a medium setting (**Do not leave this to boil continuously**)
5. Once the boiler is almost empty, refill (if needed) by using jugs or large containers, as the appliance will be very hot to touch so we do not advise you try to move it. Increase the temperature by turning up the control dial and repeat as above.

To turn off the Boiler:

1. Turn the control dial off. Turn the mains off and unplug the appliance.

Please note:

1. The boiler should be left to cool down before emptying any unused water.
2. **Under no circumstances let the boiler run dry**, as you could cause serious damage to the appliance
3. **Do not, lift the boiler with the tap**, this will damage the tap and cause the boiler to leak.