



SINK UNIT

YOU WILL NEED A WATER SUPPLY FROM A HOSE WHICH WILL REQUIRE A FEMALE HOSE LOCK ADAPTER.

FOR WASTE - PLACE THE PIPE IN THE PLASTIC CONTAINER AND EMPTY AS NEEDED.

TO USE THE HOT WATER YOU WILL NEED A 2K POWER SUPPLY INTO A STANDARD 3 PIN SOCKET.

PLEASE TAKE CARE WHEN USING WATER AND ELECTRIC.